



Part Code	Description	Q'ty
001	Ball linkage 1	2
002	Blade holder	2
003	Swashplate main body (upper)	1
004	Swashplate main body (lower)	1
005	Swashplate base	1
006	Main blade shaft sleeve	2
007	Hexagon socket head cap screw	2
008	Steel ball B	7
009	Steel ball C	5
010	Steering rod	1
011	Blade holder connector	2
012	Bearing	1
013	Blade controller	2
014	Rotor head outer sleeve	1
015	Ball linkage 2	16
016	Blade arrester	1
017	Rotor head inner sleeve	1
018	Rotor head transfer shaft	1
019	Flybar steering ball	2
020	Steering ball	1
021	Decoration ring	2
022	Balance bar	1
023	Principal axis	1
024	Bearing	4
025	Steel ball A	2
026	Swashplate steel ball	1
027	Connecting rod 1	5
028	Hexagon socket head cap screw	8

Part Code	Description	Q'ty
029	Plain washer (class C)	2
030	Bearing	4
031	Fixing sleeve	2
032	Main blade shaft	1
033	Cross recessed pan head tapping screw	2
034	Cross recessed countersunk flat head screw	6
035	Thrust bearing	1
036	Balance block	2
037	Hexagon socket pan head locking screw	9
038	Flybar paddle	2
039	Locking socket nut	2
040	Cross recessed pan head screw	2
041	Cross recessed pan head screw	6
042	Main frame (L)	1
043	Hexagon socket head cap screw	7
044	Bellcrank	4
045	plain washer	2
046	Rubber ring	2
047	Pointless locking screw	4
048	Upper main shaft holder	1
049	Retaining aluminum ring	1
050	Bearing	2
051	Lower main shaft holder	1
052	Rudder servo rod (short)	1
053	Tail boom	1
054	Horizontal stabilizer holder	1
055	Rudder servo rod lever	1
056	Rudder servo rod (long)	1
057	Rudder servo rod sleeve	1
058	Horizontal stabilizer holder	1
059	Tapping screw with washer	4
060	Horizontal stabilizer	1
061	Vertical stabilizer holder	1
062	Vertical stabilizer	1
063	Tail gear holding fixer B	1
064	Tail gear holding fixer A	2
065	Single-servo holding frame	1
066	Control bridge	1
067	Tail blade ball linkage	2
068	Tail blade connecting sleeve	1
069	Bearing	4
070	Aluminum tail blade holder	2
071	Tail rotor blade	2
072	Bearing locating ring	2
073	Bearing	2
074	Tail shaft steering holder	1
075	Bearing	2
076	Tail shaft sleeve	1
077	Tail gear holder	1

Part Code	Description	Q'ty
078	Bearing	1
079	Small pulley cover	1
080	Small pulley	1
081	Tail shaft holder	1
082	Tail shaft	1
083	Canopy fixed part	1
084	Rudder rod bellcrank	1
085	Long linkage	4
086	Bearing	1
087	Rudder servo rod lever sleeve	2
088	Tail boom holder	1
089	Gyro	1
090	Gyro holding frame	1
091	Main frame locating part	3
092	Cross recessed pan head screw	1
093	7.6g servo	3
094	Main shaft pin	1
095	Pin	1
096	Pulley	1
097	Brushless motor	1
098	Twin-servo holding frame	1
099	Drive pulley cover	1
100	7.6g Hi-speed servo	1
101	Aluminum ball	8
102	Cross recessed pan head tapping screw	8
103	Toothed synchromesh belt	1
104	Main frame (R)	1
105	Type-1 hexagonal nut	7
106	Canopy fixed part A	4
107	Tail strut	2
108	Cross recessed pan head tapping screw	8
109	Main frame (side)	1
110	Skid landing gear	2
111	Skid landing	2
112	Casing cap	4
113	Main frame	1
114	Canopy	1
115	Battery	1
116	Receiver	1
117	Principle axis sleeve	1
118	Bearing	1
119	Main gear set	1
120	Main gear shaft sleeve	1
121	Oneway bearing	1
122	Drive pulley cover	1
123	Pinion	1
124	Bearing transmission sleeve	2
125	Motor holder	1